

ПРАЙС - ЛИСТ

ЗАПРАВКА И ВОССТАНОВЛЕНИЕ КАРТРИДЖЕЙ ДЛЯ СТРУЙНЫХ ПРИНТЕРОВ

09 ноября 2009г.

Модель печатающего устройства	Модель картриджа	Цвет картриджа	Заправка картриджа
Струйные картридж Epson			
Epson stylus photo 870/890/895/900/915/1270/1290/1290S	T007091	Black	150
Epson stylus photo 870/890/895/915	T008091	Color	250
Epson stylus photo 900/1270/1290/1290S	T009091	Color	250
Epson stylus 480/580/C20SX/40UX/3000	T013401	Black	100
Epson stylus 480/580/C20SX/40UX/3000	T014402	Color	150
Epson stylus photo 810/830/830U/925/935	T026091	Black	100
Epson stylus photo 810/830/830U/925/935	T027091	Color	250
Epson stylus photo 2100/2200	T0341	Black	150
Epson stylus photo 2100/2200	T0342	Cyan	150
Epson stylus photo 2100/2200	T0343	Magenta	150
Epson stylus photo 2100/2200	T0344	Yellow	150
Epson stylus photo 2100/2200	T0345	Light Cyan	150
Epson stylus photo 2100/2200	T0346	Light Magenta	150
Epson stylus photo 2100/2200	T0347	Gray	150
Epson stylus photo 2100/2200	T0348	Matte Black	150
Epson stylus C42/C42SX/C42UX	T036	Black	100
Epson stylus C42/C42SX/C42UX	T037	Color	250
Epson stylus C43UX/C45	T038091	Black	100
Epson stylus C43UX/C45	T039091	Color	250
Epson stylus C62/CX3200	T040	Black	100
Epson stylus C62/CX3200	T041	Color	250
Epson stylus C84/C86/CX6400/CX6600	T0431	Black	150
Epson stylus C84/C86/CX6400/CX6600	T0442	Cyan	150
Epson stylus C84/C86/CX6400/CX6600	T0443	Magenta	150
Epson stylus C84/C86/CX6400/CX6600	T0444	Yellow	150
Epson stylus C63/C65/CX3500	T0461	Black	150
Epson stylus C63/C65/CX3500	T0472	Cyan	150
Epson stylus C63/C65/CX3500	T0473	Magenta	150
Epson stylus C63/C65/CX3500	T0474	Yellow	150
Epson stylus photo R200/R220//R300/R300ME/340/RX500/RX600/620/640	T0481	Black	150
Epson stylus photo R200/R220//R300/R300ME/340/RX500/RX600/620/640	T0482	Cyan	150
Epson stylus photo R200/R220//R300/R300ME/340/RX500/RX600/620/640	T0483	Magenta	150
Epson stylus photo R200/R220//R300/R300ME/340/RX500/RX600/620/640	T0484	Yellow	150
Epson stylus photo R200/R220//R300/R300ME/340/RX500/RX600/620/640	T0485	Light Cyan	150
Epson stylus photo R200/R220//R300/R300ME/340/RX500/RX600/620/640	T0486	Light Magenta	150
Epson stylus photo R800/R1800	T0541	Photo Black	150
Epson stylus photo R800/R1800	T0542	Cyan	150
Epson stylus photo R800/R1800	T0543	Magenta	150
Epson stylus photo R800/R1800	T0544	Yellow	150
Epson stylus photo R800/R1800	T0547	Red	150
Epson stylus photo R800/R1800	T0548	Blue	150
Epson stylus photo R800/R1800	T0549	Matte Black	150
Epson stylus photo R800/R1800	T0540	Gloss Optimiser	150
Epson Stylus C67/C87/CX3700/CX4100/CX4700	T0631	Black	150
Epson Stylus C67/C87/CX3700/CX4100/CX4700	T0632	Cyan	150
Epson Stylus C67/C87/CX3700/CX4100/CX4700	T0633	Magenta	150
Epson Stylus C67/C87/CX3700/CX4100/CX4700	T0634	Yellow	150
Epson Stylus C68	T066	Black	150
Epson Stylus C68	T067	Color	250
Epson stylus 440/460/640/660/669	S020187	Black	150
Epson stylus 740/740I/760/860/1159	S020189	Black	150
Epson stylus photo 740/740I/760/860/1159	S020191	Color	250
Epson Stylus PICTURE MATE	T557040	Black	550
Epson Stylus PICTURE MATE	T557040	Color	550
Струйные картридж Canon			
Canon BCI 2000/2100/4100/4200/4300/4400/4550/4650/5100/S100	BCI-21B	Black	150
Canon BCI 2000/2100/4100/4200/4300/4400/4550/4650/5100/S100 Color	BCI-21C	Color	150
Canon BCI S200/S300/PIXMA ip1000/ip1500/ip2000/MP130/MP110	BCI-24B	Black	100

Canon BCI S200/S300/PIXMA ip1000/ip1500/ip2000/MP130/MP110	BCI-24C	Color	150
Canon BCI 6000/3000/3010/6100/6200/6500/F300/600/S450	BCI-3eBK	Black	150
Canon BCI 6000/3000/3010/6100/6200/6500/F300/600/S450	BCI-3C	Cyan	150
Canon BCI 6000/3000/3010/6100/6200/6500/F300/600/S450	BCI-3M	Magenta	150
Canon BCI 6000/3000/3010/6100/6200/6500/F300/600/S449	BCI-3 Y	Yellow	150
Canon BCI F860/F870/S600/ip4000/ip5000/ip6000	BCI-6BK	Black	150
Canon BCI F860/F870/S600/ip4000/ip5000/ip6000	BCI-6M	Magenta	150
Canon BCI F860/F870/S600/ip4000/ip5000/ip6000	BCI-6Y	Yellow	150
Canon BCI F860/F870/S600/ip4000/ip5000/ip6000	BCI-6C	Cyan	150
Canon BCI F860/F870/S600/ip4000/ip5000/ip6000	BCI-6PC	Photo Cyan	150
Canon BCI F860/F870/S600/ip4000/ip5000/ip6000	BCI-6PM	Photo Magenta	150
Canon IP8600/IP8100/MP900/MP790	BCI-6G	Green	150
Canon IP8600/IP8100/MP900/MP790	BCI-6R	Red	150
Canon IP1200/1300/1600-1800/2200/2500/MP160-180/MP450MP460	PG40	Black	250
Canon IP1200/1300/1600-1800/2200/2500/MP160-180/MP450MP460	PG41	Color	350
Canon IP2200/MP150-180/MP450MP460	PG50	Black	250
Canon IP2200/MP150-180/MP450MP460	PG51	Color	350
Canon IP3300/IP3500/IP4200/ IP 4300 /IP4500	BCI-8BK	Black	150
Canon IP3300/IP3500/IP4200/ IP 4300 /IP4500	BCI-8C	Cyan	150
Canon IP3300/IP3500/IP4200/ IP 4300 /IP4500	BCI-8M	Magenta	150
Canon IP3300/IP3500/IP4200/ IP 4300 /IP4500	BCI-8Y	Yellow	150
Canon IP3300/IP3500/IP4200/ IP 4300 /IP4500	BCI-8PC	Photo Cyan	150
Canon IP3300/IP3500/IP4200/ IP 4300 /IP4500	BCI-8PM	Photo Magenta	150
Canon BGC240/250/1000	BC02	Black	250
Canon BGC240/250/1000	BC05	Color	350
Canon BGC240/250/1000	BC06	Color	350
Canon BGC-2000/4000/5500/100	BC20	Black	250
Струйные картридж Lexmark			
Lexmark Z735/X2349	LX 1	Color	350
Lexmark I3/X74/X75/X1100/X1200/X2200/Z13/X23/Z25/Z33/Z35/Z500/Z600	LX16	Black	250
Lexmark I3/X74/X75/X1100/X1200/X2200/Z13/X23/Z25/Z33/Z35/Z500/Z600	LX 17	Black	250
Lexmark I3/X74/X75/X1100/X1200/X2200/Z13/X23/Z25/Z33/Z35/Z500/Z600	LX 26	Color	350
Lexmark I3/X74/X75/X1100/X1200/X2200/Z13/X23/Z25/Z33/Z35/Z500/Z600	LX 27	Color	350
Lexmark P700/P3100/Z12/Z22/Z32/Z705/Z707/Z710/Z715/lj599	LX 50	Black	250
Lexmark 3200/5000/5700/7000/7200/Optra Color40/45/F4200/X63/X73/X79	LX 70	Black	250
Струйные картридж Hewlett-Packard			
Hp 400/420c/500/500c/510/520/540/550c/200/220/600/520/c	51626AE	Black	250
Hp 600/660c/670c/500/590	51629AE	Color	350
Hp 710c/720c/722/815c/700/750c/1150c/1170c	51645AE	Black	250
Hp 350c/640c/600/635/725/740/500/590	51649AE	Color	350
Hp 710c/720c/722/815c/700/750c/1150c/1170c	C1823DE	Color	350
Hp 916c/920c/930c/cm/220/230/	C6578D	Color	350
Hp 610c/615c/640c/656c/925xi/1020	C6614DE	Black	250
Hp 810c/ 816c/ 825c/ 840c/ 843c/ 845c/ v30/ v40/ v45/ 500/ 750	C6615D	Black	250
HP 816c/ 825 /840c/ 843c /845c	C6625AE	Color	350
Hp 450xi/450cdi/4105/4110/4215/4219/4252/4255	C6656A	Black	250
Hp 450xi/450cdi/4105/4110/4215/4219/4252/4255	C6657AE	Color	350
Hp 450xi/450cdi/4105/4110/4215/4219/4252/4255	C6658AE	Color	350
Hp 3320/3325/3420/3425/3520/1110/1200/120S/1210/1213/1215	C8727AE	Black	250
Hp 3320/3325/3420/3425/3520/1110/1200/120S/1210/1213/1215	C8728AE	Color	350
Hp 5743/5943/6543/6543/6623/6313/7213	C8767HE	Black	250
HP 460c/1513/1513s/2573/3213/7313/7413	C8765HE	Black	250
Hp 460c/460cd/325/375/385/428/475/1513/1513s	C8766HE	Color	350
Hp 3920/3940/D1360/D1460/D1470/D1560/D2330/D1560/590	C9351AE	Black	250
Hp 3920/3940/D1360/D1460/D1470/D1560/D2330/D1560/590	C9352AE	Color	350
HP 5443/D4163/6313/2573/1513/1513S/C3183	C9361HE	Color	350
HP 5443/D4163/6313/2573/1513/1513S/C3183	C9362HE	Black	250
Hp 460c/460cd/325/375/385/428/475/1513/1513s	C9363HE	Color	350
HP 5943/ 6943/ 6983/ D4163/ 6313	C9364HE	Black	250
HP D2563/F4283	CC643HE	Color	350
HP D4263/5783/5283/D5363	CB335HE	Black	250
HP D4263/5783/5283/D5363	CB336HE	Color	350
HP 5783	CB337HE	Black	250
HP 5783	CB338HE	Color	350
Струйные картридж Brother			
Brother MFC 210C/MFC410CN/MFC620CN/Fax1840c/fax1835C/MFC640CW	LC900	Black	250
Brother MFC 210C/MFC410CN/MFC620CN/Fax1840c/fax1835C/MFC640CW	LC900	Cyan	250
Brother MFC 210C/MFC410CN/MFC620CN/Fax1840c/fax1835C/MFC640CW	LC900	Magenta	250
Brother MFC 210C/MFC410CN/MFC620CN/Fax1840c/fax1835C/MFC640CW	LC900	Yellow	250
Brother 130C/330C/350C/353C/357C/540CN/560CN/750CW/770CW	LC1000	Black	250
Brother 130C/330C/350C/353C/357C/540CN/560CN/750CW/770CW	LC1000	Cyan	250
Brother 130C/330C/350C/353C/357C/540CN/560CN/750CW/770CW	LC1000	Magenta	250
Brother 130C/330C/350C/353C/357C/540CN/560CN/750cw/770CW	LC1000	Yellow	250

Компания «Картридж Мастер» покупает струйные б/у картриджи у физических и юридических лиц.

ПЕРВЫЙ СОРТ – отработанный оригинальный картридж после одного использования с неповрежденным корпусом.

ВТОРОЙ СОРТ - перезаряженный или восстановленный картридж без повреждения корпуса.

Справки по телефону 466-300